



VCF-1 Schematic: Sheet 1 of 2

- For best temperature stability, R11 should be in thermal contact with matched pair Q1/Q2.
- For less critical applications, Q1/Q2 may be replaced with a pair of 2N3906 transistors and R11 may be an ordinary resistor.

© 2010 Thomas Henry